
(in programming mode) Stealth Button Guide



Preprogrammed Cycle Buttons

commercial blenders-not the least of which is the state-of-the-art control surface that allows you to manage and fine-tune your blender's programming. The Blendtec Stealth incorporates the latest technology available in today's

Selecting a Profile

To select a profile, follow the steps below:

- Touch to select Profiles Enter programming mode by touching and holding (s) for 3 seconds
- To choose 1 of the standard profiles preprogrammed on the
- To choose a custom profile designed via the Blend Wizard, machine, select Standard Profiles by touching (
- touch (◆) to scroll to Custom Profiles and then touch (◆)
- After selecting the standard or custom profile category, touch to scroll through the profiles in the category, and touch (v) to select the desired profile.
- The LED screen will list the selected profile and the question "Make this the active profile?" Touch (a) to load the blender with the profile, or touch to cancel and return to the previous menu

Changing the Programmed Cycle Buttons

the blend cycles in the profile: After loading the desired profile, complete the following steps to change 1 of

- Enter programming mode by touching and holding (x) for 3 seconds
- Touch to scroll to the second menu item (Blend Cycles), and then touch
- Select the first or second option. The first option (Standard Blend the first or second option by touching (designed via the Blend Wizard and exported to the blender. Select option (Custom Blend Cycles) lists the custom cycles that can be Cycles) lists the cycles preprogrammed on the blender. The second

- Touch to scroll to the desired cycle, and then touch
- The LED screen will then prompt you to choose which number on the control surface you want to assign the cycle to. Touch the number, and then touch () to program the button with the selected cycle.

Creating Profiles and Cycles via the Blend Wizard™

visit blendtec.com/commercial/program on using the Blend Wizard to easily develop custom profiles and cycles include currend Blendtec cycles and/or custom cycles. For instructions blender, you can use the Blend Wizard to create custom profiles that In addition to using the profiles and cycles preprogrammed on your

Importing Custom Profiles and Cycles to the Blender

Once you have completed the Blend Wizard instructions and transferred a file to the blender. custom profile file to a USB flash drive, follow the steps below to import the

- Use a Phillips screwdriver to remove the USB cover at the top of the right side of the blender.
- Insert the USB flash drive into the blender's USB port
- If the blender is in manual or automatic operation mode, the USE screen is already in programming mode, go to the main menu touch to scroll to menu item 5 (USB Flash Drive), and then drive menu will automatically load on the LED screen. If the LED touch@
- (Import Profile). From the USB flash drive menu, touch to select option 1
- desired custom profile file (by default named stealth.bpf). (Note: Items the desired file by touching (3). with a + sign next to them are folders; if the custome profile file is in a Touch to scroll through the items on the flash drive and locate the folder, touch to open the folder and see the files in the folder.) Selec
- the custom profile will be automatically loaded as the active profile on Touch (a) to start the import process. After the file has been imported the blender.
- the USB port with a Phillips Screwdriver. Remove the USB drive from the blender, and secure the USB cover or

Owner's manual. For detailed operation instructions, refer to Section 5 of the Stealth

Pulse at Speed

Pulse

Preloaded Blending Profiles

0	5	4	ω	N			7	0	5	4	ω	10	_	
50 Seconds at Speed 7	Large Smoothie 2	Granita / Medium Milkshake	Small Stushy / Milkshake	Large lee Cappuccino	Small Margarita / Ree Cappuccino	Coffee Profile	Pulse at Speed 7	50 Seconds at Speed 7	Large Smoothie 4	Medium Smoothie 3	Granita / Medium Milkshake	Medium Smoothie 4	Small Smoothie with Fresh Fruit	Smoothie Profile
50 seconds	seconds	14 seconds	12 seconds	20 seconds	14 seconds		Pulse	500 seconds	40 seconds	23 Seconds	14 seconds	25 seconds	20 seconds	
0	5	4	ω	N	_		7	0	5	4	ω	N	_	
Large Milkshake 3	Large Milkshake 2	Large Milkshake 1	Milkshake with Frozen Fruit	Granita / Medium Milkshake	Small Milkshake	Milkshake Profile	Pulse at Speed 7	50 Seconds at Speed 7	Large Smoothie 4	Medium Smoothie 4	Small Margarita / Ice Cappuccino	Granita / Medium Milkshake	Small Milkshake	Multipurpose Profile
seconds S	27 seconds	24 seconds	seconds	14 seconds	Seconds		Pulse	500 seconds	40 seconds	25 Seconds	seconds	14 seconds	100 seconds	ofile